SET-TOP BOX
Remote Guide

TV POWER

Red - Recordings
Green - All Shows
Yellow - PulseTV Guide
Blue - All Movies

TV APP GUIDE
Shows apps on your TV outside of PulseTV

GOOGLE VOICE CONTROL
Searches for your voice command request outside of PulseTV app

VOLUME (UP/DOWN)
Controls volume if paired with TV

INFO
Description of show or channel in PulseTV

SEARCH
Search for channels or shows on PulseTV

REMOTE BATTERY
Lights up when remote batteries are low and need replaced

SET-TOP BOX POWER

A - Replay on Pulse TV
B - Recently Watched
C - Settings

RECORD
Only allowed on select live channels

HOME
Takes you back to the home of set-top box (outside of PulseTV)

CHANNEL (UP/DOWN)

SUBTITLES/CAPTIONS

PREVIOUS CHANNEL
Takes you back to the last channel you were watching on PulseTV

🎤 **Voice Command Note**

To search within PulseTV's App Navigate to the search icon in the main menu, then select the microphone icon on the screen to activate voice control. Using the Google Assistant button on the remote will exit the PulseTV app

LOVELAND
pulseTV